Important Assembly Note:

When attaching the backrest, only attach the backrest screws loosely (2-3 revolutions per screw) before aligning and connecting armrests. Once armrests are completely connected, go back and tighten down the backrest screws completely.

